

ENG

USER INSTRUCTION

Use the product for intended purposes only as specified in this manual. Mishandling the product can lead to its breakage and cause harm to the user or damage to his/her assets.

- Do not put the thermometer in the oven while cooking.
- Do not touch the front part of the thermal probe with bare hands.
- Do not immerse the digital thermometer in liquid.
- This product is not a toy. Children should not use this product.
- Before each use, you can insert the metal probe into boiling water to sterilize the metal probe.

FEATURE

- Built-in magnet on the back – can be attached to a refrigerator.
- Max./Min. temperature record.
- When the temperature is less than 40°C and does not fluctuate over ±3°C, the thermometer will automatically shut down if the probe is unrolled and no button is pressed for 5 minutes. After automatic shutdown, you can press any key to turn the thermometer on.
- °C/°F switchable.
- Increments: 0.1 °C.
- Measuring range: -50°C–300°C(-58°F–572°F). It is recommended to use the thermometer with a temperature below 230°C(446°F).

OPERATING INSTRUCTIONS

- 1.Before using the thermometer, remove the protective film from the front panel.
- 2.Unroll the metal probe to turn on the thermometer. The current temperature will be displayed on screen in Celsius.
- 3.The default display unit is Celsius. If you want to interchange between Celsius and Fahrenheit, press the °C/°F/CAL Button.
- 4.Insert the probe into food to measure the temperature.
- 5.Press the HOLD/MAX/MIN button before removing the probe from the food to save the temperature reading.
- 6.Long press the HOLD/MAX/MIN button to retrieve the maximum recorded temperature. Short press the button afterward to retrieve the minimum recorded temperature. Then, short press the button to exit the recorded temperature display.
- 7.Restarting the thermometer will reset the MAX/MIN record.
- 8.To turn on the backlight on the screen, press the light button. The backlight will go out after a few seconds.

ENG

- 9.Replace battery: Rotate the back cover anticlockwise to open it. Put in a new CR2032 battery and then secure the cover.
- 10.Manual calibration:
 - Hold °C/°F/CAL for 3 seconds until "CAL" is displayed.
 - Adjustment range: -2°C to +2°C.
 - At 0°C calibration: Displays an error "Err" and flashes if calibration is outside ±2°C.
 - Use the backlight button to increase by +0.1°C/°F (long press = faster). Use HOLD/MAX/MIN to decrease by -0.1°C/°F. Max. adjustment: ±2°C/°F.
 - When "PASS" is displayed, the calibration is done correctly.

CLEANING AND STORAGE

- Clean the metal probe with towel soaked with soapy water. Do not use abrasives.
- Wipe the outer surface of the main body with a soft, slightly damp cloth. Avoid getting water inside the main body and never wash the product under water.
- Wipe the product dry after each cleaning.
- Store the product in a well-ventilated and not high temperature place.

SORTING GUIDELINES

Electrical and electronic equipment contains materials, components, and substances that may be hazardous and harmful to human health and the environment if waste electrical and electronic equipment (WEEE) is not disposed of properly. Products marked with a "crossed-out wheeled bin" symbol are electrical and electronic equipment. This symbol indicates that such waste must not be disposed of with unsorted household waste but must be collected separately. To facilitate this, all municipalities have established collection systems where waste electrical and electronic equipment can be dropped off free of charge at recycling centers or other collection points, or in some cases picked up directly from households. Further information should be obtained from your local municipal technical department.

Sołczyk

DIGITALT STEGE
TERMOMETER

BRUGERMANUAL



DK

BRUGERVEJLEDNING

Vigtigt: Brug kun produktet som angivet i denne manual. Forkert brug kan føre til beskadigelse af produktet, personskade eller skade på ejendele.

- Termometeret må ikke placeres i ovnen under madlavning.
- Undgå at røre ved den forreste del af temperaturføleren med bare hænder.
- Nedsænk aldrig det digitale termometer i væske.
- Produktet er ikke legetøj – Må ikke anvendes af børn.
- Før hver brug kan du sterilisere metalproben ved at sætte den i kogende vand

FUNKTIONSBESKRIVELSE

- Indbygget magnet på bagsiden – kan sættes på køleskab.
- Hukommelse for maks./min.temperatur-funktion.
- Automatisk slukning: Når temperaturen er under 40°C og ikke varierer mere end ±3°C, slukker termometeret automatisk efter 5 minutter, hvis proben er foldet ud og ingen knap er trykket. En vilkårlig knap tænder enheden igen.
- Skift mellem °C og °F.
- Temperaturtrin: 0,1 °C.
- Måleområde: -50°C til 300°C (-58°F til 572°F). Anbefalet brugstemperatur: under 230°C (446°F)

BETJENINGSVEJLEDNING

- 1.Fjern beskyttelsesfilmen fra frontpanelet før termometret tages i brug.
- 2.Fold metalproben ud for at tænde termometeret – temperaturen vises i Celsius.
- 3.For at skifte mellem Celsius og Fahrenheit: Tryk på knappen °C/°F/CAL.
- 4.Indfør proben i fødevaren for at måle temperaturen.
- 5.Tryk på HOLD/MAX/MIN-knappen inden du fjerner proben, for at gemme temperaturmålingen.
- 6.Hold HOLD/MAX/MIN-knappen nede for at vise maksimal temperatur. Kort tryk efterfølgende viser den minimale temperatur. Et yderligere kort tryk afslutter visningen.
- 7.Genstart af termometeret nulstiller MAX/MIN-hukommelsen.
- 8.Tryk på lysknappen for at aktivere baggrundsbelysning. Den slukker automatisk efter få sekunder.

DK

- 9.Batteriskift: Drej bagdækslet mod uret for at åbne. Udskift med et nyt CR2032 batteri og fastgør dækslet igen.
- 10.Manuel kalibrering:
 - Hold °C/°F/CAL nede i 3 sekunder, indtil "CAL" vises.
 - Justeringsområde: -2°C til +2°C.
 - Ved 0°C kalibrering: Viser en fejl "Err" og blinker, hvis kalibreringen er uden for ±2°C.
 - Brug baggrundsls-knappen til at øge med +0,1°C/°F (langt tryk = hurtigere). Brug HOLD/MAX/MIN til at mindske med -0,1°C/°F. Maks. justering: ±2°C/°F.
 - Når "PASS" vises, er kalibreringen udført korrekt.

RENGØRING OG OPBEVARING

- Rengør metalproben med en klud opvredet i sæbevand. Brug ikke slibende midler.
- Tør kabinetdelen af med en blød, let fugtet klud. Undgå at få vand ind i hovedenheden. Produktet må aldrig vaskes under rindende vand.
- Tør termometeret helt af efter rengøring.
- Opbevares tørt og væk fra høje temperaturer.

SORTERINGSVEJLEDNING

Elektrisk og elektronisk udstyr indeholder materialer, komponenter og stoffer, der kan være farlige og skadelige for menneskers sundhed og for miljøet, når affaldet af elektrisk og elektronisk udstyr (WEEE) ikke bortskaffes korrekt. Produkter, der er mærket med "overkrydsede skraldespand", er elektrisk og elektronisk udstyr. Den krydsede skraldespand symboliserer, at affald af elektrisk og elektronisk udstyr ikke må bortskaffes sammen med usorteret husholdningsaffald, men skal indsamles særskilt. Til dette formål har alle kommuner etableret indsamlingsordninger, hvor affald af elektrisk og elektronisk udstyr gratis kan afleveres af borgerne på genbrugsstationer eller andre indsamlingssteder eller hentes direkte fra husholdningerne. Nærmere information skal indhentes hos kommunens tekniske forvaltning.

Produceret for og importeret af:
Stock Group A/S Gammelmarksej 11
DK- 7100 Vejle
www.stockgroup.dk
MADE IN CHINA

